Car Remote key Supplier

Declaration:
All photos and descriptions only for reference .
The directories involved in the trademarks and designations authorized manufacturers and users, we just use it to describe products characters.

www.kigoauto.com

kigoauto®

—— Shanghai Kaigao Auto Electrics Co.,Ltd

A Professional Auto Remote Supplier

目录 TABLE OF contents

9**** Remote key & Smart key(FOB) 02

8**** Remote key & Smart key case 26

7**** Smart key blade 55

6**** Transponder key (blank) 60

5*** Refit flip key shell 66

4*** Remote key blade 73

3*** Remote buttons 76

9155901	9155902	9155903	9155904
Smart key 3button 8T0 959 754C 315mhz	Smart key 3button 8T0 959 754C 434mhz	Smart key 3button 8T0 959 754C 868mhz	Smart key 3button 8T0 959 754G 315mhz
9155905	**9155906**	**9102901**	**9102902**
Smart key 3button 8T0 959 754G 434mhz	Smart key 3button 8T0 959 754G 868mhz	Remote key 3button 8X0 837 220G 433mhz	Remote key 3+1button IYZ3314 315mhz
9103701	**9103702**	**9103703**	**9103704**
Remote key 3button CAS system HU92 315mhz	Remote key 3button CAS system HU92 434mhz	Remote key 3button EWS system HU92 315mhz	Remote key 3button EWS system HU92 434mhz
9103801	**9103802**	**9103803**	**9103804**
Remote key 3button CAS system HU58 315mhz	Remote key 3button CAS system HU58 434mhz	Remote key 3button EWS system HU58 315mhz	Remote key 3button EWS system HU58 434mhz
9137801	**9137802**	**9145501**	**9145502**
Remote key 3button ID44 LX8 FZV 315mhz	Remote key 3button ID44 LX8 FZV 434mhz	Smart key 3button ID46 1YZKEY5602 315mhz	Smart key 3button ID46 1YZKEY5602 434mhz

9145503	9144504	9144505	9145201
Smart key 3button ID46 1YZKEY5602 868mhz	Smart key 3button	Smart key 4button	Smart key 3button KR55WK49863 315mhz
91567	**9145203**	**9145204**	**9145205**
Smart key 4button KR55WK49863 315mhz YGOHUF5662 434mhz	Remote key 3button	Remote key 4button	Remote key 3button
9145206	**9103901**	**9103902**	**9103903**
Remote key 3button	Smart key 3button KR55WK49127 315mhz	Smart key 3button KR55WK49127 434mhz	Smart key 3button KR55WK49127 868mhz
9103904	**9104001**	**9104002**	**9104003**
Smart key 3button KR55WK49127 315LP	Smart key 4button LX8766S 315mhz	Smart key 4button LX8766S 434mhz	Smart key 4button LX8766S 868mhz
9104004	**9214601**	**9214602**	**9214603**
Smart key 4button LX8766S 315LP	REFIT Remote key 2button ID44 HU58 315mhz	REFIT Remote key 2button ID44 HU58 434mhz	REFIT Remote key 2button HU92 315mhz

9214604

REFIT Remote key 2button
HU92 434mhz

9149902

Smart key 5button

9149903

Smart key 5button

9149904

Smart key 6button

9149001

Smart key 4button
OUC6000066

9149002

Smart key 5button
OUC6000066

9149003

Smart key 6button
OUC6000066

9149201

Smart key 4button

9149202

Smart key 5button

91500

Smart key 4button
M3N5WY7777A

9136800

Fobik key 2button
M3N5WY783X 434mhz

9136801

Fobik key 3button
M3N5WY783X 434mhz

9136802

Fobik key 3button
M3N5WY783X 434mhz

9136803

Fobik key 4button
M3N5WY783X 434mhz

9136804

Fobik key 3button
M3N5WY783X 434mhz

9136805

Fobik key 4button
M3N5WY783X 434mhz

9136806

Fobik key 4button
M3N5WY783X 434mhz

9136807

Fobik key 5button
M3N5WY783X 434mhz

9136808

Fobik key 4button
M3N5WY783X 434mhz

9136809

Fobik key 5button
M3N5WY783X 434mhz

9136810

Fobik key 6button
M3N5WY783X 434mhz

9137200

Fobik key 2button
IYZ-C01CS 434mhz

9137201

Fobik key 3button
IYZ-C01CS 434mhz

9137202

Fobik key 3button
IYZ-C01CS 434mhz

9137203

Fobik key 4button
IYZ-C01CS 434mhz

9137204

Fobik key 3button
IYZ-C01CS 434mhz

9137205

Fobik key 4button
IYZ-C01CS 434mhz

9137206

Fobik key 4button
IYZ-C01CS 434mhz

9137207

Fobik key 5button
IYZ-C01CS 434mhz

9137208

Fobik key 4button
IYZ-C01CS 434mhz

9137209

Fobik key 5button
IYZ-C01CS 434mhz

9137210

Fobik key 6button
IYZ-C01CS 434mhz

9137300

Fobik key 2button
M3N5WY783X 434mhz

9137301

Fobik key 3button
M3N5WY783X 434mhz

9137302

Fobik key 3button
M3N5WY783X 434mhz

9137303

Fobik key 4button
M3N5WY783X 434mhz

9137304

Fobik key 3button
M3N5WY783X 434mhz

9137305

Fobik key 4button
M3N5WY783X 434mhz

9137306

Fobik key 4button
M3N5WY783X 434mhz

9137307

Fobik key 5button
M3N5WY783X 434mhz

Remote key & Smart key(FOB)

9137308

Remote key 4button
M3N5WY783X 434mhz

9137309

Fobik key 5button
M3N5WY783X 434mhz

9137310

Fobik key 6button
M3N5WY783X 434mhz

9137100

Fobik key 4button
IYZ-C01C 315/434mhz

9137101

Fobik key 3button
IYZ-C01C 315/434mhz

9137102

Fobik key 3button
IYZ-C01C 315/434mhz

9137103

Fobik key 4button
IYZ-C01C 315/434mhz

9137104

Fobik key 3button
IYZ-C01C 315/434mhz

9137105

Fobik key 4button
IYZ-C01C 315/434mhz

9137106

Fobik key 4button
IYZ-C01C 315/434mhz

9137107

Fobik key 5button
IYZ-C01C 315/434mhz

9137108

Fobik key 4button
IYZ-C01C 315/434mhz

9137109

Fobik key 5button
IYZ-C01C 315/434mhz

9137110

Fobik key 6button
IYZ-C01C 315/434mhz

9148901

Remote key 3button
OHT692427AA 315mhz

9148902

Remote key 3button
M3N5WY72XX 315mhz

9148903

Remote key 4button
OHT692427AA 315mhz

9148904

Remote key 4button
M3N5WY72XX 315mhz

9148905

Remote key 5button
OHT692427AA 315mhz

9148906

Remote key 5button
M3N5WY72XX 315mhz

9148907

Remote key 6button
OHT692427AA 315mhz

9148908

Remote key 6button
M3N5WY72XX 315mhz

9148909

Remote key 4button
OHT692427AA 315mhz

9148910

Remote key 4button
M3N5WY72XX 315mhz

9148911

Remote key 2button
4589199AC 434mhz

9148912

Remote key 3button
4589199AC 434mhz

9148913

Remote key 4button
KOBDT04A 315mhz

9148914

Remote key 3button
KOBDT04A 315mhz

9147901

Smart key 2button
M3N-40821302 434mhz

9147902

Smart key 3button
M3N-40821302 434mhz

9147903

Smart key 4button
M3N-40821302 434mhz

9147904

Smart key 4button
M3N-40821302 434mhz

9147905

Smart key 5button
M3N-40821302 434mhz

9147906

Smart key 4button
GQ4-54T 434mhz

9147907

Smart key 5button
GQ4-54T 434mhz

9125602

Remote fob 2button
GQ43VT10T 315mhz

9125603

Remote fob 3button
GQ43VT5T/GQ43VT7T 315mhz

9125604

Remote fob 3button
GQ43VT7T 315mhz

9125601

Remote fob 3button
GQ43VT17T 315mhz

9125701

Remote fob 4button
GQ43VT17T 315mhz

Remote key & Smart key(FOB)

9125702

Remote fob 6button
GQ43VT18T

91161

Remote key 2button
ID46 NE72 434mhz

91164

Remote key 2button
ID46 VA2 434mhz

91808

Remote key 2button
ID46 NE78 434mhz

91166

Remote key 2button
ID46 SX9 434mhz

91162

Remote key 2button
ID46 HU83 434mhz

9165101

Remote flip key 2button
HU83/VA2 434mhz
CE0523

9165102

Remote flip key 2button
HU83/VA2 434mhz
CE0536

9116801

Remote flip key 3button
HU83/VA2 Middle light
434mhz CE0523

9116802

Remote flip key 3button
HU83/VA2 Middle light
434mhz CE0536

9155001

Remote flip key 3button
HU83/VA2 Middle trunk
434mhz(CE0536/CE0523)

9155002

Remote flip key 3button
HU83 Middle trunk
434mhz(PEU408)

9180601

Remote key 3button
ID63 M3N5WY8610
315mhz

9180602

Remote key 4button ID63
HU101 M3N5WY8610
315mhz

9180603

Remote key 3button
ID63 M3N5WY8610
315mhz

9180604

Remote key 4button
ID63 M3N5WY8610
315mhz

91566

Remote key 3button
CWTWB1U793
315mhz/434mhz

91487

Remote key 4button
CWTWB1U793
315mhz/434mhz

91354

Remote key 5button
CWTWB1U793
315mhz/434mhz

9121301

Remote fob 3button
434mhz

9121302

Remote key 3button
FO21 3M5T15K601AB
4D60 434mhz

91289

Remote key 3button
HU101 3M5T15K601AB
4D63 434mhz

91356

Remote key 3button
ID63 AM5T15K601AD
313mhz

9152601

Smart key 3button
DS7T-15K601-DB
434mhz

91502

Remote key 4button
N5F-A08TAA 315mhz

9121201

Remote key 3button
HU101 KR55WK47899
434mhz

9121202

Remote key 3button
FO21 KR55WK47899
434mhz

91226

Blue remote fob 3button
434mhz

91653

Remote fob 3button
AU215K601A 434mhz

91652

Remote fob 4button
AU215K601A 434mhz

91538

Remote fob 3button
434mhz

91539

Remote fob 4button
434mhz

91563

Remote fob 2button
CWTWB1U331 434mhz

9122401

Remote fob 3button 315mhz
CWTWB1U511/CWTWB1U345

9122402

Remote fob 3button
CWTWB1U345 434mhz

9122501

Remote fob 4button 315mhz
CWTWB1U331/CWTWB1U345

91361

Remote fob 5button 315mhz
CWTWB1U551/WTWB1U345

9122403

REFIT flip key 3button
CWTWB1U331 315mhz

9122404

REFIT flip key 3button
CWTWB1U331 315mhz

9122502

REFIT flip key 4button
CWTWB1U331 315mhz

9149101

Remote fob/control 6button
GOH-PCGEN2 433mhz

9149102

Remote fob/control 4button
GOH-PCGEN2 433mhz

9149401

Smart key 5button
M3N5WY8609 315mhz

9149402

Smart key 4button
M3N5WY8609 315mhz

91468

Smart key 4button
M3N5WY8406 315mhz

9152602

Remote key 4button
M3N-A2C31243300
315mhz

9123301

Remote key 2button 315mhz
V2T01060512/V2T01060514

9123302

Remote key 2button 433mhz
V2T01060512/V2T01060514

9133201

Remote key 3button 315mhz
V2T01060512/V2T01060514

9133202

Remote key 3button 433mhz
V2T01060512/V2T01060514

9123501

Remote key 3button 315mhz
V2T01060512/V2T01060514

9123502

Remote key 3button 433mhz
V2T01060512/V2T01060514

9133301

Remote key 4button 315mhz
V2T01060512/V2T01060514

9133302

Remote key 4button 433mhz
V2T01060512/V2T01060514

9123401

Remote key 4button 315mhz
V2T01060512/V2T01060514

9123402

Remote key 4button 433mhz
V2T01060512/V2T01060514

9123601

Remote key 5button 315mhz
V2T01060512/V2T01060514

9123602

Remote key 5button 433mhz
V2T01060512/V2T01060514

91331

Remote key 3button
4D60 315mhz

91400

Remote key 3button
4D60 315mhz

9123101

Remote key 3button
DW05 315mhz/434mhz
4D60/48

9123102

Remote key 4button
DW05 315/434mhz
4D60/48

91232

Remote key 4button
DW05 315/434mhz
13chip

91230

Remote key 5button
DW05 315/434mhz
13chip

9124202

Remote key 2button
HU43VS-VZ 304.2mhz

9124203

Remote key 3button
HU43VS-VZ 304.2mhz

91448

Remote key 2button
ID46 434/315mhz

91425

Remote key 3button
ID46 434/315mhz

91227

Remote key 2button
IT7RK700NR 315mhz

9124902

Smart key 4button
M3N32337100 315mhz

9124903

Smart key 5button
M3N32337100 315mhz

9124904

Smart key 6button
M3N32337100 315mhz

9124905

Smart key 4button
M3N65981403 315mhz

9124906

Smart key 6button
HYQ1AA 315mhz

9157201

Remote flip key 2+1button
92245048 ID46 434mhz

9157301

Remote flip key 3+1button
92213311 ID46 434mhz

9149301

Remote flip key 4+1button
OUC6000083 ID46 315mhz

9157202

Remote key fob 2+1button
92245048 434mhz

9157302

Remote key fob 3+1button
92213311 434mhz

9149302

Remote key fob 4+1button
OUC6000083 315mhz

Remote key & Smart key(FOB)

91243

Remote fob 2button
L2C0007T 315mhz

91390

Remote fob 3button
L2C0007T 315mhz

91244

Remote fob 4button
L2C0007T 315mhz

91392

Remote fob 4button
L2C0007T 315mhz

91393

Remote fob 5button
L2C0007T 315mhz

9124602

Remote fob 3button
MYT3X6898B/LHJ011/
LHJO11 315mhz

9124603

Remote fob 3button
L2C0005T 315mhz

9124601

Remote fob 4button
AB00204T/ KOBLEAR1XT/
KOBUT1BT 315mhz

91247

Remote fob 4button
AB00204T/ KOBLEAR1XT/
KOBUT1BT 315mhz

91377

Remote fob 3button
OUC60221/OUC60270/
KOBGT04A 315mhz

91587

Remote fob 4button
OUC60221/OUC60270/
KOBGT04A 315mhz

91248

Remote fob 4button
KOBGT04A15788021
315mhz

91571

Remote fob 5button
KOBGT04A 315mhz

91589

Remote fob 4button
OUC60221/OUC60270/
KOBGT04A 315mhz

9124502

Remote fob 5button
OUC60221/OUC60270/
KOBGT04A 315mhz

9124503

Remote fob 5button
OUC60221/OUC60270
315mhz

91590

Remote fob 5button
15114376 315mhz

9159101

Remote fob 6button
15114376 315mhz

9159102

Remote fob 6button
OUC60221/OUC60270
315mhz

9159103

Remote fob 5button
OUC60221/OUC60270
315mhz

91583

Remote key 2button
315mhz

91582

Remote key 3button
315mhz

91597

Remote key 4button
315mhz

9110601

Remote key 2button
OUCG8D-380H-A
434mhz

9110602

Remote key 2button
MLBHLIK-1T 434mhz

9110603

Remote key 2button
VDO 72147-TAO-W2
434mhz

9110701

Remote key 3button
OUCG8D-380H-A
313.8/315/434mhz

9110702

Remote key 3button
MLBHLIK-1T
434mhz

9110703

Remote key 3button
VDO 72147-TAO-W2
434mhz

9110801

Remote key 3button
OUCG8D-380H-A
313.8/315mhz

9110803

Remote key 3button
KR55WK49308
434mhz

9110804

Remote key 3button
MLBHLIK-1T
313.8mhz

9110802

Remote key 3button
N5F-S0084A
313.8/315/434mhz

9110901

Remote key 4button
OUCG8D-380H-A
313.8mhz

9101904

Remote key 4button
CWTWBIU545
315/434mhz

9110902

Remote key 4button
KR55WK49308
313.8/315/434mhz

9101903

Remote key 4button
N5F-S0084A
313.8/315/434mhz

9110905

Remote key 4button
MLBHLIK-1T
313.8mhz

91098

Remote fob 2button
434mhz

91099

Remote fob 3button
434mhz

Remote key & Smart key(FOB)

91414

Remote fob 3button
A269ZUA106 434mhz

91100

Remote fob 4button
A269ZUA101 434mhz

91521

Remote fob 5button
OUCG8D-399H-A
313.8mhz

91522

Remote fob 6button
OUCG8D-399H-A
313.8mhz

91569

Remote fob 5button
OUCG8D-440H-A
313.8mhz

91523

Remote key 3button
MLBHLIK6-1T 313.8mhz

91524

Remote key 4button
MLBHLIK6-1T 313.8mhz

9153101

Smart key 2button
434mhz

9153102

Smart key 3button
434mhz

9153103

Smart key 4button
315mhz

9153104

Smart key 5button
315mhz

9153105

Smart key 4button
A2C32523300 315mhz

9153106

Smart key 6button
315mhz

9163401

Remote fob 2button

9163402

Remote fob 3button

9163403

Remote fob 3button
E4EG8d-444H-A
309mhz

9163405

Remote fob 3button
OUCG8D-355H-A
314mhz

9148601

Smart key 2button
434mhz

9148602

Smart key 3button
434mhz

9148603

Smart key 4button
ACJ8D8E24A04
434mhz

99111

Remote key 3button
954302B210/81996A4000/
819261U000 433mhz

91599

Remote key 3button
434mhz

91600

Remote key 3button
434mhz

91603

Remote key 3button
434mhz

91604

Remote key 3button
434mhz

91601

Remote key 3button
434mhz

9160202

Remote key 3button
434mhz

9160201

Remote key 3button
434mhz

9131801

Remote key 1button
434mhz (L)

9131802

Remote key 1button
434mhz (R)

91144

Remote fob 2button
OSLOKA-850T
315mhz/434mhz

91145

Remote fob 2+1button
PINHA-T036
315mhz/434mhz

91146

Remote fob 3button
PLNHM-T011
315mhz/434mhz

91147

Remote fob 3+1button
315mhz/434mhz

91143

Remote fob 2button
311/315/434mhz

9115801

Remote fob 3button
311/315/434mhz

9115802

Remote fob 4button
KR55WY8404 315mhz

9147702

Smart key 3button
Ix35 434mhz

91552

Smart key 4button
Ix35 434mhz

91554

Smart key 4button

Remote key & Smart key(FOB)

91574

Remote key 4button
SY5KHFNA04
315mhz/434mhz

91598

Remote key 4button
OSLOKA-OKA870T
315mhz/434mhz

91428

Remote key transmitter
NHVWB1U241 315mhz/
1X43-15K801-BD 434mhz

9142803

Remote key 4button ID60
NHVWB1U241 315mhz

9142804

Remote key 4button ID60
1X43-15K801-BD 434mhz

9148103

Smart key 5button
CW93-15K601-AB
315mhz

9148104

Smart key 5button
CW93-15K601-BB
434mhz

9139701

Smart key 5button
EX53-15K601-BD
434mhz

9139702

Smart key 5button
EW93-15K601-AC
315mhz

91482

Smart key 5button
KOBJTF10A 315mhz

91251

Remote key 2button
HU92 434mhz

91252

Remote key 2button
434mhz

91253

Remote key 2button
434mhz

9125401

Remote key LR4 ID44
HU92 315/434mhz

9125402

Remote key LR4 ID44
HU101 315/434mhz

9125403

Remote key LR3 ID46
HU92 315/434mhz

9125404

Remote key LR3 ID46
HU101 315/434mhz

9125501

Remote key 3button
ID46 315mhz/434mhz

9125502

Remote key 3button
ID44 315mhz/434mhz

9148101

Smart key 5button
KOBJTF10A 315mhz

9148102

Smart key 5button
KOBJTF10A 315mhz

9139601

Smart key 5button
315mhz

91483

Smart key 315/434mhz
KR55WK49244/
KR55WK45694

9139603

Smart key 5button
315mhz

9132901

Remote key 2button
Mazda3 315mhz

9132902

Remote key 2button
Mazda3 434mhz

9132903

Remote key 2button
Mazda6 315mhz

9132904

Remote key 2button
Mazda6 434mhz

9159601

Remote key 3button
Mazda3 315mhz/434mhz

9159602

Remote key 3button
Mazda6 315mhz/434mhz

91593

Remote key 3button
BGBX1T478SKE12501
315mhz

91592

Remote key 4button
BGBX1T478SKE12501 315mhz/
KPU41788 314mhz

9146001

Smart key 2button
315mhz

9146002

Smart key 2button
434mhz

9146003

Smart key 3button
KR55WK49383
WAZSKE13D01 315mhz

9146004

Smart key 4button
WAZSKE13D01 315mhz

9146005

Smart key 4button
315mhz

9146006

Smart key 3button
WAZSKE13D01 315mhz

91527

Remote fob 2button
433mhz

9159401

Remote fob 3button
KPU41846 315mhz

Remote key & Smart key(FOB)

9159402

Remote fob 4button
KPU41805

9143202

Smart key 2button
315mhz

91433

Smart key 3button
315mhz

91434

Smart key 3button
BGBX1T458SKE11A01
315mhz

9143201

Smart key 4button
BGBX1T458SKE11A01
315mhz

91052

Remote key 4button
KR55WK49031 315mhz

91053

Remote key 3button
434mhz

91547

Remote key 4button
IYZDC11 315mhz

91546

Remote key 3button
434mhz

9138902

Remote key 3button
IYZDC07 315mhz

9138901

Remote key 2button
434mhz

91325

Remote key 3button
434mhz

91451

Remote key 4button
315mhz

91326

Remote key 3button
434mhz

91348

Remote key 1button
434mhz

91140

Remote key 2button
ID46LCK 315/434mhz

91284

Remote key 2button
4D61 315/434mhz

91139

Remote key 3button
ID46/4D61 434mhz

91285

Remote key 3button
ID46/4D61 434mhz

91629

Smart key 4button
OUC644M-KEY-N

91435

Remote fob 2button
E4EG8D-522M-A/
HYQ12ABA 315mhz

91436

Remote fob 3button
OUCG8D-525M-A/
HYQ12BBA 315mhz

9113805

Remote key 3button(Left)
OUCG8D-620M-A 315mhz

9113806

Remote key 3button(Right)
OUCG8D-620M-A 315mhz

9113807



Remote key 4button(Left)
OUCG8D-620M-A 315mhz

9113808

Remote key 4button(Right)
OUCG8D-620M-A 315mhz

91110

Remote key 1button
315mhz

9145001

Smart key 3button
KR55WK48903 with notch
315mhz

9145002

Smart key 3button
CWTWBU729 No notch
315mhz

9145003

Smart key 3button
KBRTN001 No notch
315mhz

9145004

Smart key 4button
KR55WK48903 with notch
315mhz

9145005

Smart key 4button
CWTWBU729 No notch
315mhz

9145006

Smart key 4button
KBRTN001No notch
315mhz

9145007

Smart key 3button
with notch 434mhz

9145008

Smart key 3button
No notch 434mhz

91513

Remote key 3button
ID46KBRASTU15 315mhz

91514

Remote key 4button
ID46KBRASTU15 315mhz

91115

Remote fob fob 4button
NHVBU27/NHVWBU43
315mhz

91118

Remote fob 3button
KBRASTU15/CWTWB1U429
315mhz

9111901

Remote fob 4button
KBRASTU15/CWTWB1U429
315mhz

Remote key & Smart key(FOB)

9111902

Remote fob 5button
KBRASTU51 315mhz

9111903

Remote fob 6button
KBRASTU51 315mhz

91342

Remote key 2button
CWTWB1U751 315/434mhz

91344

Remote key 3button
CWTWB1U751 315/434mhz

91343

Remote key 3button
CWTWB1U751 315/434mhz

91345

Remote key 4button
CWTWB1U751 315/434mhz

9136001

Remote fob 3button
GQ43VT8T 315mhz

9136002

Remote fob 4button
A269ZUA078 434mhz

9157502

Smart key card 3utton
315mhz

9156801

Smart key 4button
KR55WK48903 with notch
315mhz

9156802

Smart key 4button
No notch
CWTWBU619 315mhz

9156803

Smart key 3button
KR55WK49622 with nocth
315mhz

9156804

Smart key 3button
CWTWBU619 No notch
315mhz

91803

Remote key fob 2button
433mhz

91191

Remote key fob 2button
433mhz

91192

Remote fob 3button
433mhz

91194

Remote key 2button
434mhz

91193

Remote key 3button
HU101 434mhz

9145401

Remote key 5button
315mhz

9145402

Remote key 2button
434mhz

91187

Remote key 2button
ID40 434mhz

91189

Remote key 2button
ID40 434mhz

91324

Remote key 2button
434mhz

91406

Remote key 3button
KR55WK45022 434mhz

91407

Remote key 2+1button
315mhz

91408

Remote key 3+1button
KR55WK45032 315mhz

91507

Remote key 3button
315mhz

91506

Remote key 2button
315mhz

91429

Remote key 1button
315mhz

91430

Remote key 2button
315mhz

91431

Remote key 3button
315mhz

9137601

Smart key 3button
433mhz

9137602

Smart key 3button
434mhz

91169

Remote key 2button
PCF7946/PCF7947
Ne73 433mhz

91170

Remote key 3button
PCF7946/PCF7947
NE73 433mhz

91171

Remote key 2button
PCF7946/PCF7947
VA6 433mhz

91172

Remote key 3button
PCF7946/PCF7947
VA6 433mhz

91173

Remote key 2button
PCF7946/PCF7947
VAC102 433mhz

91174

Remote key 3button
PCF7946/PCF7947
VAC102 433mhz

91175

Remote key 1button
PCF7946/PCF7947
NE73 433mhz

Remote key & Smart key(FOB)

91619

Remote key 1button
PCF7946/PCF7947
NE73 433mhz

91178

Remote key 2button
VAC102 ID46 433mhz

91283

Smart key card 3button
PCF7946/PCF7947
433mhz

91421

Smart key card 4button
PCF7946/PCF7947
433mhz

91391

Smart key card 2button
PCF7946/PCF7947
433mhz

91157

Remote key 2button
87170-08B31 433mhz

91206

Remote key 3button
Id62 434mhz

91207

Remote key 3button
Id62 434mhz

91209

Remote key 4button
315mhz

91208

Remote key 4button
315mhz

91205

Remote key 4button
315mhz

91201

Remote key 2button
ID46 OUCG8D-380H-A
313mhz

9138202

Remote key 2button
NHVWB1U711 315mhz

9138203

Remote key 3button
CWTWB1U819 315mhz

9138201

Remote key 3button
434mhz

9119501

Remote key 2button
KBRTS004 HU133 SX4
315mhz/433mhz

9119502

Remote key 2button
KBRTS004 HU133 SWIFT
315mhz/433mhz

9119503

Remote key 4button
KBRTS009 315mhz

9147801

Smart key 2button
KBRTS003

9147802

Smart key 3button
KBRTS003

9106301

Remote key 3button
4D67/4C/No chip
304mhz

9106302

Remote key 3button
4D67/4C/No chip
315mhz

9106303

Remote key 3button
4D67/4C/No chip
433mhz

9106304

Remote key 3button
89071-60081 4C
433mhz

91071

Remote key 2button
314.2/315.1/434mhz

91072

Remote key 3button
315mhz/433mhz

9107001

Remote key 3button
315mhz/433mhz

91065

Remote key 4button
314mhz/433mhz

9107401

Remote key 4button
HYQ12BBY 314mhz/
GQ429T 315mhz

9107402

Remote key 4button
433mhz

9107501

Remote key 3button
GQ429T 315mhz/ MOZB41TG
312mhz/HYQ12BBY 314.4mhz

9107502

Remote key 3button
434mhz

91077

Remote fob 6button
GQ43VT20T 314/433mhz

91080

Remote fob 3button
315mhz

91081

Remote fob 4button
313mhz

91508

Remote fob 2+1button
HYQ12BBX 314mhz

91511

Remote fob 3+1button
HYQ12BBX 314mhz

91512

Remote fob 3+1button
HYQ12BBX 314mhz

91510

Remote fob 3+1button
HYQ12BAN 314mhz

91330

Smart key 3button
315mhz

9147401

Remote fob 2button
315mhz

9147402

Remote fob 3button
315mhz

9146901

Smart key 4button
315mhz

9146902

Smart key 4button
315mhz

9146903

Smart key 3button
315mhz

9146904

Smart key 4button
HYQ14AAB 315mhz

91624

Smart key 3button
315mhz

91625

Smart key 3button
315mhz

91627

Smart key 5button
315mhz

9147301

Smart key 3button
434mhz

9147302

Smart key 3button
434mhz

9147303

Smart key 4button
434mhz

91557

Remote key 3button
434Mhz

91555

Smart key 4button
315mhz

91581

Smart key 4button
HYQ14FBA 315Mhz

91464

Remote fob 2button
HYQ1512J

91445

Remote fob 3button
HYQ1512J 315mhz

91463

Remote fob 4button
HYQ1512J

91446

Remote fob 4button
HYQ12AAA

91447

Remote fob 4button
HYQ12AAA

91416

Remote key 4button
HYQ12AAA

9100101

Remote key fob 2button
1J0 959 753 N 434mhz

9100102

Remote key fob 2button
1J0 959 753 AG 434mhz

9100105

Remote key fob 2button
1J0 959 753 G 434mhz

9100104

Remote key 2button ID48
1J0 959 753 N 434mhz

9100201

Remote key fob 3button
1J0 959 753 DJ 315mhz/
1J0 959 753 N 434mhz

9100202

Remote key fob 3button
1J0 959 753 AG 434mhz

9100203

Remote key 3button ID48
1J0 959 753 N 434mhz/
1J0 959 753 DJ 315mhz

9100103

Remote key 2button ID48
5K0 837 202 AD 434mhz

9100204

Remote key 3button ID48
5K0 837 202 AD 434mhz

9100301

Remote key fob 3+1button
1JO 959 753 T 315mhz

9100302

Remote key 3+1button ID48
1JO 959 753T 315mhz

9102701

Remote key 3+1button ID48
300 959 753 AA 315mhz

9102702

Remote key 3button ID48
300 959 753 AA 434mhz

9138101

Smart key 3button
7P6 959 754 AS
315mhz/434mhz

9138102

Smart key 3button
7P6 959 754AP
315/434/868mhz

91545

Smart key 3button ID48
3C0 959 752 BA 434Mhz

More remotes updating...

Remote key & Smart key(FOB)

81470	8145601	8145602	81350
81351	**8102901**	**8102902**	**81006**
81011	**81012**	**81013**	**81014**
81008	**81028**	**8213301**	**81031**
81032	**81033**	**81034**	**81037**

81038	81378	81036	81455
8144504	**8144505**	**8145201**	**81567**
8145203	**8145204**	**8145205**	**8145206**
81039	**81040**	**81411**	**82146**
8149902	**8149903**	**8149904**	**8149001**

Remote key & Smart key case

8149002	8149003	8149201	8149202
81500	**8136800**	**8136801**	**8136802**
8136803	**8136804**	**8136805**	**8136806**
8136807	**8136808**	**8136809**	**8136810**
8137200	**8137201**	**8137202**	**8137203**

8137204	8137205	8137206	8137207
8137208	**8137209**	**8137210**	**8137300**
8137301	**8137302**	**8137303**	**8137304**
8137305	**8137306**	**8137307**	**8137308**
8137309	**8137310**	**8137100**	**8137101**

Remote key & Smart key case

8137102	8137103	8137104	8137105
8137106	**8137107**	**8137108**	**8137109**
8137110	**8148901**	**8148903**	**8148905**
8148907	**8148910**	**8148911**	**8148912**
8148913	**8148914**	**8148915**	**8148916**

8147901	8147902	8147903	8147904
8147905	**8147906**	**8147907**	**8125602**
8125603	**8125604**	**8125605**	**8125606**
8125601	**8125701**	**8125702**	**81161**
81164	**81808**	**81166**	**81162**

Remote key & Smart key case

Jeep

81651	81168	81550	81424
81160	**81420**	**8141801**	**8141802**
81269	**81268**	**81458**	**8144101**
8144102	**8180601**	**8180602**	**8180603**
8180604	**81566**	**81487**	**81354**

81213	81211	8121302	8135601
8135602	**8152601**	**8152602**	**81502**
8121201	**8121202**	**81212**	**81214**
81215	**81226**	**81653**	**81652**
81538	**81539**	**81563**	**8122401**

Remote key & Smart key case

8122402	8122501	8136101	8149101
8146803	**8148001**	**8148002**	**8146801**
81233	**81332**	**81235**	**81234**
81333	**8123601**	**8123602**	**81331**
81400	**8123101**	**8123102**	**81232**

8123001	8123002	81231	8123201
8123202	**8124201**	**8124202**	**8124203**
81448	**81425**	**81227**	**8124902**
8124903	**8124904**	**8124906**	**8157202**
9157302	**9149302**	**81366**	**8157201**

Remote key & Smart key case

8157301	9149301	81493	8124901
8144402	**8144401**	**81243**	**81390**
81244	**81392**	**81393**	**8124602**
8124603	**8124601**	**81247**	**81377**
81587	**81248**	**81571**	**81589**

8124501	8124504	81590	8159101
8159102	**8159103**	**8124905**	**81583**
81582	**81597**	**81106**	**81107**
81108	**81109**	**81101**	**81102**
8160602	**8160603**	**9160604**	**81098**

Remote key & Smart key case

81099	81414	81100	8160601
81521	**81522**	**81520**	**81519**
81569	**81523**	**81524**	**81394**
81553	**8148601**	**8148602**	**8148603**
8153101	**8153102**	**8153103**	**8153104**

8153105	8153106	8163401	8163402
8163403	**8163404**	**89111**	**81599**
81600	**81603**	**81604**	**81601**
8160202	**8160201**	**8131801**	**8131802**
81144	**81145**	**81146**	**81147**

81143	8115801	8115802	8147701
8147702	**81552**	**81554**	**81541**
81540	**81537**	**81621**	**81574**
81558	**81605**	**81598**	**8149103**
8149104	**8120001**	**8120002**	**8142801**

8142802	8142803	8139703	9139701
81253	**81251**	**81252**	**81482**
81254	**81255**	**81483**	**8139601**
8139603	**81635**	**9148101**	**8148102**
89167	**81415**	**81329**	**81596**

Remote key & Smart key case

81593	81592	8146001	8146003
8146004	**8146005**	**8146006**	**91527**
8159401	**8143202**	**81433**	**81434**
8143201	**8149105**	**8149102**	**8159402**
81128	**81129**	**81052**	**81053**

81547	81546	8138902	8138901
81051	**8105001**	**8163601**	**8163602**
81049	**81048**	**81047**	**81046**
81451	**81326**	**81325**	**81348**
81650	**81498**	**81140**	**81284**

Remote key & Smart key case

81139	81285	8113802	8113804
8113801	**8113803**	**81628**	**81629**
81576	**81630**	**8113501**	**8113502**
8137501	**81435**	**81436**	**8145701**
8145702	**8145001**	**8145002**	**8145004**

8145005	8145007	8145008	81118
8111901	**8111902**	**8111903**	**81342**
81344	**81343**	**81345**	**8112303**
8112401	**8112402**	**8112301**	**8112302**
81110	**81116**	**81117**	**8157502**

8157501	8136001	8136002	8156803
8156804	**8156801**	**8156802**	**81115**
81614	**81191**	**81803**	**81192**
81181	**81182**	**81183**	**81193**
81194	**8145401**	**8145402**	**81190**

81187	81189	81802	81188
81324	**81406**	**81407**	**81408**
81506	**81507**	**81429**	**81430**
81431	**81376**	**8213302**	**81169**
81170	**81171**	**81172**	**81173**

Remote key & Smart key case

81174	8161901	8161902	81618
8117801	**8117802**	**81175**	**81283**
81421	**8139101**	**8139102**	**8131401**
8131402	**8142603**	**8142602**	**8142601**
81440	**81615**	**81616**	**81617**

81157	81207	81209	81208
81206	**81205**	**8138203**	**8138202**
8138201	**81202**	**81201**	**8119901**
8119902	**81195**	**8147801**	**8147802**
8119503	**8106101**	**81062**	**81066**

81067	81068	81069	81064
81063	**8106102**	**8106103**	**8107101**
8107102	**8107002**	**81556**	**8107001**
81073	**81065**	**81075**	**81074**
8150801	**8151101**	**8151201**	**8151001**

8150802	8151102	8151202	8151002
8107702	**8107701**	**8107902**	**8107901**
9147301	**9147302**	**9147303**	**8147401**
8147402	**81549**	**81560**	**81466**
81613	**81612**	**81467**	**8109401**

Remote key & Smart key case

8109402	8109403	8109404	8108101
81330	**81631**	**81632**	**81557**
81555	**81581**	**8146901**	**8146902**
8146903	**8146904**	**81623**	**81624**
81625	**81627**	**81580**	**8108102**

81475	81080	81622	81633
81095	**81497**	**91464**	**91445**
91463	**91446**	**91447**	**8141601**
9141602	**8141603**	**8141604**	**8141605**
8141606	**81609**	**81611**	**81610**

Remote key & Smart key case

81608	8100101	9100104	8100201
8100203	**8100301**	**8100302**	**8100103**
8100204	**8102702**	**8102701**	**8154501**
8154503	**8154502**	**8103001**	**81016**
8154504	**8213303**	**81381**	**81011**

7138301	7138302	71018	7138702
7138701	**71386**	**71293**	**71035**
70568	**70036**	**70035**	**71352**
71228	**7122901**	**7122902**	**7143701**
7143702	**71259**	**7064901**	**7064902**

71534	7144102	7144103	71461
71223	**70526**	**71654**	**7148002**
7148003	**70400**	**70601**	**7144301**
7144302	**70551**	**71531**	**7153301**
7153302	**71532**	**71562**	**7150501**

7150502	7150503	7141001	7141002
7140901	**7140902**	**7156101**	**7156102**
71315	**7139703**	**71488**	**7139602**
71495	**71449**	**71801**	**71403**
71060	**7105901**	**7105902**	**71057**

Smart key blade

71058	71395	71422	71291
7112101	**7112102**	**71122**	**71288**
71472	**71341**	**71362**	**71180**
71398	**71399**	**71287**	**7142301**
7142302	**109001**	**109002**	**7109003**

7109004	7109005	7148401	7148402
71088	**7108901**	**7108902**	**71413**
71096	**7109701**	**7109702**	**71488**
71404	**71019**	**71017**	**70634**
7143801	**7143802**	**71565**	**71564**

61023	61024	61041	61042
Key blank HU66 ID48	Key blank HU49 ID48	Key blank HU58 ID44	Key blank HU92 ID44
61043	**61044**	**61045**	**61320**
Key blank HU92 ID44	Key blank HU58 ID44	Key blank HU92 ID44	Key blank Y160 4D64
61321	**61322**	**61442**	**61176**
ID46LCK	NO chip	POD key blank CY22/CY24 ID46LCK	Transponder key blank SX9 ID46
61162	**61328**	**61542**	**61266**
Man HU83	HU83 ID46/VA2 ID46	Transponder Key NE72 ID45	Transponder key blank SIP22 48chip
61267	**6121702**	**6121801**	**6121901**
Transponder key shell GT15R 48chip	Transponder key shell FO38 4C glass	Transponder key FO21 ID60	Transponder key FO38 4D63

6122001	6121802	61294	61270
Transponder key HU101 4D63	Non chip key blank	Transponder key FO38 4D63	Transponder key FO38 4D63
6124101	**6124102**	**6138801**	**6138802**
Transponder key PK3 ID46LCK	Transponder key B99 ID46LCK	Transponder key HU46	Transponder key YM28
6138803	**6138804**	**6180701**	**61295**
Transponder key HU100	Transponder key HU43	Transponder key B97 ID13	Transponder key ID48
6110302	**61105**	**61503**	**61151**
Transponder key ID46	Transponder key HON58R ID46/ID48	Key shell HON66	HYN11L 4D60/46chip
61152	**61153**	**61154**	**61380**
HYN7R 4D60/46chip	HYN14L ID46chip	HYN14R ID46chip	HY20 ID46chip

6141701	6141702	6115602	6115601
HY18 ID46chip	HYN6	HYN6	KIA3R
6115603	**6115604**	**61530**	**6113001**
HYN14L	HYN14R	KIA7	Transponder key 4D63
61515	**61054**	**6105502**	**61056**
Transponder key MZD24 8C/ID63	Transponder key HU39 ID44	Transponder key HU64 ID44	YM15 key T5
61327	**6113401**	**6113402**	**61111**
Key blank MB100	Transponder key shell MIT11R	Transponder key shell MIT8L	Non-transponder key NSN14
61120	**6133801**	**61365**	**6111201**
Transponder key NSN14 ID46/ID60	Key blank NSN14 ID46/4D60	Transponder key NSN14 ID46/4D60	Key blank NSN14 ID46

6111202	61384	6118401	6118402
Key blank NSN14 ID46	Transponder key blank NSN14	Key blank HU46	Transponder key HU46
61185	**6118601**	**6134901**	**6134902**
Transponder key HU43	Key blank HU100	Key blank YM28 ID40/ID46	Transponder key YM28
61810	**61319**	**61203**	**61204**
Key blank NE72	Transponder key with light	Transponder key blank NSN19 T21/4D62	Transponder key blank NSN11 ID33
6121001	**6121002**	**61197**	**6119801**
Transponder key DAT17 shell	Transponder key DAT17 ID62	Transponder key shell HU87 4D-65	Transponder key shell SZ19 TOY43
61086	**61809**	**61082**	**61083**
Transponder key shell	Transponder key 4C	Key shell TOY43	Transponder key TOY43 4C/4D67

Transponder key (Blank)

61086	61271	61353	61015
Key shell TOY48 long	Transponder key blank NE66	Transponder key HU56 ID73/ID4M	Key shell with light HU66
61020	**6102102**	**6102501**	**61026**
Transponder key HU49	Transponder key HU49	key blank HU66 round head	Transponder key HU66 ID48
61306	**61307**	**61273**	**61311**
Motorcycle key	Motorcycle key	Motorcycle key	Motorcycle key
61312	**61275**	**60280**	**60281**
Motorcycle key	Motorcycle key	Motorcycle key	Motorcycle key
60282	**61302**	**61804**	**61308**
Motorcycle key	Motorcycle key	Motorcycle key	Motorcycle key

6127401	61272	61277	61278
Motorcycle key	Motorcycle key	Motorcycle key	Motorcycle key
61304	**61305**	**61276**	**61303**
Motorcycle key	Motorcycle key	Motorcycle key	Motorcycle key
60279	**61309**	**61301**	
Motorcycle key	Motorcycle key	Motorcycle key	

More remotes updating...

5001	5002	5003	5004
5005	**5006**	**5007**	**5008**
5009	**5010**	**5011**	**5012**
5013	**5014**	**5015**	**5016**
5017	**5018**	**5019**	**5020**

5021	5022	5023	5024
5026	**5027**	**5028**	**5029**
5030	**5031**	**5032**	**5033**
5034	**5035**	**5036**	**5037**
5038	**5025**	**5040**	**5041**

5042	5043	5044	5045
5046	**5047**	**5048**	**5049**
5050	**5051**	**5039**	**5052**
5053	**5029**	**5056**	**5057**
5058	**511302**	**511301**	**5035**

5037	5129	5112	5170
5172	**5171**	**5190**	**5191**
5192	**5193**	**5085**	**5086**
5087	**5088**	**5079**	**5080**
5081	**5084**	**5082**	**5163**

5098	5099	5100	5101

5103	5173	5174	5131

5130	5076	5077	5074

5073	5106	5184	5108

5114	5175	5176	5180

5181	5182	5183	5120

5121	5107	5177	5185

5186	5189	5187	5188

517801	517802	517803	517804

517901	517902	517903	517904

5146	5154	5139	5092
515503	**515504**	**5123**	**5122**
5195	**5196**	**5197**	**5198**
506402	**506401**	**5066**	**5071**
5141	**5142**	**507201**	**507202**

#01	#02	#03	#04	#05	#06
					
VW/Audi HU49	Toyota TOY43	Honda HON58R	Chrysler CY22	Toyota	NISSAN NSN11
#07	**#08**	**#09**	**#10**	**#11**	**#12**
					
Mitsubishi MIT11R	KIA/Daewoo	MAZDA	Suzuki	Mercedes HU39	Isuzu
#13	**#14**	**#15**	**#16**	**#17**	**#18**
					
Lexus TOY40	Isuzu	Chevrolet/Hyundai/ Ssangyong/Kia	Mitsubishi	Citroen	BMW HU58
#19	**#20**	**#21**	**#22**	**#23**	**#24**
					
Ford FO38	Mercedes HU64	Toyota TOY38R	Nissan NSN14	Mitsubishi/Suzuki	Volvo NE66

#25	#26	#27	#28	#29	#31
Honda HON66	GM Buick	Mazda MZD24R	Hyundai/KIA	Hyundai	VW HU66

#33	#34	#35	#36	#37	#38
					
Hyundai	KIA	Suzuki	Hyundai	Daihatsu	Ford HU101

#39	#40	#41	#50	#52	#53
					
Buick/Chevrolet	Chevrolet	Ford FO21	Hyundai	Suzuki	Peugeot NE72

#54	#58	#60	#61	#62	#64
					
Peugeot HU83	Citroen	Fiat GT15R	Buick	Mitsubishi MIT8	Mazda MZD24R

#67	#68	K01	#71	#72	#73
					
BMW HU92	Citroen SX9	Citroen	GM/OPEL new profile	Citroen	Peugeot

#75	#79	#80	#82	#378	#85
					
Ford	Opel	Opel	Opel	Hyundai/KIA	Hyundai

#86	#93	K53	K66	K07	K62
					
KIA	Toyota	Citroen	Citroen	Mitsubishi	Mitsubishi

K07	K79	K43	K28	K51	K41
Renault	Holden	Citroen	Porsche	Smart	Citroen

4 Remote key blade

3001	3002	3003	3004	3005
3006	**3007**	**3008**	**3009**	**3010**
3011	**3012**	**3013**	**3014**	**3015**
3016	**3017**	**3018**	**3019**	**3020**
3021	**3022**	**3023**	**3024**	**3025**
3026	**3027**	**3028**	**3029**	**3030**

3031	3032	3033	3034	3035
3036	**3037**	**3038**	**3039**	**3040**
3041	**3042**	**3043**	**3044**	**3045**
3046	**3047**	**3048**	**3049**	**3050**
3051	**3052**	**3053**	**3054**	**3055**
3056	**3057**	**3058**	**3059**	**3060**

3061	3062	3063	3064	3065
3066	**3067**	**3068**	**3069**	**3070**
3071	**3072**	**3073**	**3074**	**3075**
3076	**3077**	**3078**	**3079**	**3080**
3081	**3082**	**3083**	**3084**	**3085**
3086	**3087**	**3088**	**3089**	**3090**

3091	3092	3093	3094	3095
3096	**3097**	**3098**	**3099**	**3100**
3101	**3102**	**3103**	**3104**	**3105**
3106	**3107**	**3108**	**3109**	**3110**
3111	**3112**	**3113**	**3114**	**3115**
3116	**3117**	**3118**	**3119**	**3120**